

STOP STICK®

STOP STICK® MOUNTING TRAY Installation Instructions



Tools Required:

- Drill
- 1/8 Drill Bit
- Pop-rivet gun
- Tape measure
- Straight edge
- Duct tape
- Scissors
- Pencil

IMPORTANT SAFETY NOTES

- Secure trunk lid open during installation to avoid injury.
- Do not bend the Stop Sticks or the Stop Stick tray during installation.
- Do not crush the Stop Stick housing.
- Wear safety goggles during installation to avoid injury to eyes.
- Additional information is available at www.stop-stick.com
- an Installation Guide may be requested from Stop Stick, Ltd. by calling 1-800-537-0102

STEPS:

1. View Training/ Installation video.
2. Open shipping box and inspect contents: 1 MOUNTING TRAY, with 3 (9 Foot) / 4 (12 Foot) STOP STICKS, 1 Replacement STOP STICK, 1 CORD REEL, 1 SLEEVE, 6 Rivets and Installation Instructions.
3. Remove sleeved STOP STICKS from MOUNTING TRAY.
4. Cut two 8" strips of Tape: one for each end of MOUNTING TRAY; affix these to overhang the edges of the MOUNTING TRAY.
5. Open trunk. Place MOUNTING TRAY against inside of trunk lid with reflective decal on MOUNTING TRAY right side up.
6. Move MOUNTING TRAY around on ribbing of trunk lid to lay as flat as possible, close to bottom (hinge side) of trunk as possible and still lay flat on lid ribbing.
7. Tape MOUNTING TRAY in place until measurements can be taken.



STEPS: (Continued)

8. Measure for evenness, height and width from edges of trunk lid and adjust if necessary.
9. Use straight edge and pencil; mark MOUNTING TRAY where ribbing passes beneath MOUNTING TRAY. This makes drilling through MOUNTING TRAY into ribbing more accurate.
10. Drill 1/8" hole through the MOUNTING TRAY and through the ribbing, being careful not to drill through trunk lid surface; you should drill about one inch from edge of the MOUNTING TRAY.



11. Using a pop rivet gun, fasten MOUNTING TRAY to trunk lid ribbing. Rivets are shallow, tight, and flat fasteners; they work better than screws because screws have heads that dig into the STOP STICKS over time and screws may cause surface marks on trunk lid surface.
12. Check to make sure the MOUNTING TRAY is even. Then drill other end of MOUNTING TRAY and rivet in place. Drill remaining holes and install rivets, putting 2 rivets on each end of MOUNTING TRAY. Use a minimum of four rivets to hold the MOUNTING TRAY in place.



If the trunk ribbing intersects the center of the MOUNTING TRAY, install the remaining rivets in this area. If the trunk lid has a curve to it and the MOUNTING TRAY does not lay flat on the center ribbing, Do Not rivet the Center of the MOUNTING TRAY because it will curve the MOUNTING TRAY and the STOP STICKS will not fit properly.

13. Remove tape from the MOUNTING TRAY.
14. Using the metal clip on the CORD REEL, attach the CORD REEL to grommet at the end of the SLEEVE. This prevents the sticks from coming out of the SLEEVE during installation in the MOUNTING TRAY. Place the sleeved STOP STICKS in the MOUNTING TRAY, using the velcro straps to hold it in place. Make sure the red handles stick out and that the sticks fit back into the lips of the MOUNTING TRAY. The red handles on the SLEEVE aid in deployment. Keep the velcro straps of the MOUNTING TRAY loose until you have positioned the sleeved STOP STICKS. The sleeved STOP STICKS may be placed in either direction, depending on whether you are right or left handed.
15. Be sure to fasten the velcro straps with the metal tabs on the outside, facing upwards. This positions the straps for easy access during deployment.
16. The CORD REEL can be mounted with the sleeved STOP STICKS utilizing the MOUNTING TRAY velcro straps. Loosen one of the straps placing the CORD REEL flat on sleeved STOP STICKS. Loop the velcro strap around the CORD REEL handle and fasten.
17. Your STOP STICKS are now ready for deployment

Should you have any questions, please reference Training / Installation video or contact Stop Stick, Ltd., 1-800-537-0102.